

INSTRUCTION MANUAL

使用說明 / 使用说明


momax *smart*

Smart Heat

IoT Fan Heater

IoT 智能暖風機

IoT 智能暖风机




IW5S

Product Information p.2 - 11

產品資料 p.12 - 21

产品资料 p.22 - 31



Introduction

IoT Fan Heater (IW5S)

This is a smart heater with a relatively small size design, suitable for home or office use.

Find "IW5S" in MOMAX's channel

helpdesk.momaxsmart.com

Get step-by-step setup and support.

Watch the latest video tutorial to learn to setup and operate your IW5S.

Keep up to date with the latest updates.



Quick Start Guide

1. Download 'MOMAX Smart' APP

Download "MOMAX Smart" from iOS App Store, Android Google Play Store or other platforms. Then, enable the Bluetooth function on your phone.

2. Register

Register an account and log in using your mobile number or email address.

3. Wireless Pairing

Click "+", then tap "MOMAX Smart Heater" to add device.


Please turn on the power switch on the back of the machine, then press the power button to turn on the machine. Hold the Timer button until the Wi-Fi indicator light is fast blinking. Tap "Confirm indicator rapidly blink". Then, tap "Next" to proceed.

- This product cannot be paired directly through the Bluetooth list of the mobile phone.
- The pairing process may take 2 minutes, please do not perform other operation.


4. Successfully connected

Once the connection is completed, you can edit the name of the Heater.

Product Overview



Indicator Lights	
	WiFi
	Warm air
	Hot air
	Safety lock



1. Metal cover
2. Indicator lights
3. Button
4. Dustproof filter
5. Power switch

Button	Function
 Power	<ul style="list-style-type: none"> • In Standby mode, press the power button once to enter the natural wind mode (no indicator light). Press again to enter warm air mode (warm air indicator light on). Press again to enter the hot air mode (hot air indicator light on). Then press it again to Re-enter the natural wind mode cycle. • When the heater is operating, hold the power button to turn off the machine and enter Standby mode.
 Auto-off Timer	<ul style="list-style-type: none"> • When the heater is operating, press the timer button to set the timer for 1hr, 2hr, 4hr and 8hr respectively. • The indicator light on the panel will show the remaining time of the timer. If an 8hr timer was set, while the device has operated for 4 hours, the 4H indicator light will turn on, showing that the remaining time of the timer is within 4 hours. • Long press the timer button for 5 seconds to enter Pairing mode.
 Oscillation	<ul style="list-style-type: none"> • When the heater is operating, tab the button and the fan will start to oscillate. Tab the button again to stop oscillation.
 Safety Lock	<ul style="list-style-type: none"> • When the heater is operating, hold the button for 3 seconds to turn on safety lock. When the safety lock is on, other buttons will not work. Hold the button for 3 seconds again to unlock.

Safety Features

Tip-over protection:

- Tip-over protection feature will cut off the power and turn off the PTC when the heater falls over in any direction. A notification sound will turn on for 1 min, until the heater put back to a normal direction.

Thermal overload protection:

- When turning off the heater with the power button after using warm air mode or hot air mode, the PTC heating component will be turned off first, while the fan will continue operate for 1 more minute to allow the PTC component to dissipate. If warm air mode or hot air mode have not been turned on during the operation, the fan will be turned off together with the PTC component.

Shut down protection:

- When the heater has been turned on continuously for 24 hours, it will automatically shut down and enter the standby mode..

Maintenance

Ensure the machine is unplugged before maintenance.


Cleaning:

1. Turn off and unplug the machine. Wait for the heating component to cool down.
2. Clean the dust or debris of the air inlet/outlet. Use a lightly moistened soft cloth with neutral cleanser to clean the surface of the unit.
3. Take the dustproof filter out from the back and clean it.

Warning: When wiping the air outlet, prevent water to get inside the machine.

Storage:

1. After cleaning the machine and drying it completely, put on a dust cover/bag and place it in a well-ventilated place that is not exposed directly to sunlight.
2. If not using it for a long period of time, please operate the heater for a few minutes from time to time.



Specification

Model No.	: IW55
Rated voltage/frequency	: 220-240V~, 50/60 Hz
Power	: 1500W
Working temperature	: -10 °C - 50 °C
Storage temperature	: -10 °C - 70 °C
Max. working sound level	: ≤45dB
Wireless frequency (WiFi)	: 2.4GHz
Bluetooth Version	: 4.2
Size	: 180 x 180 x 400mm
Weight	: 2.5 ± 0.2Kg

Contains

1. Smart Heat IoT Fan Heater
2. Instruction Manual And Warranty Card

Warnings

Points for attention

Before using, please read this user manual carefully and keep it for future reference.

1. To avoid overheating, do not cover the heater.
2. Do not block the air inlet and outlet, keep a distance of more than 30cm from the wall or obstacles.
3. Clean the filter regularly to avoid insufficient air intake to overheat the internal temperature.
4. Do not let water or other liquids or flammable cleaning agents enter the product to avoid electric shock or fire.
5. Do not spray insecticide, perfume or other flammable sprays around the product.
6. Before connecting the product to the power supply, please check whether the voltage marked on the bottom of the product matches the local voltage.
7. Please check whether the power cord and plug are broken or damaged before use. If the power cord is damaged, it must be replaced by the manufacturer or its service agent a similarly qualified person in order to avoid danger.
8. Do not use this product on an unstable or inclined place to avoid accidents such as injury or fire caused by product dumping. It must be placed and used on a stable, flat and level surface.
9. The product is forbidden to be sprayed with water or liquid to avoid dangers such as short circuit and electric shock.
10. Do not use this product in high temperature, humidity or volatile places.
11. Do not use this product around the bathtub or swimming pool.
12. Do not place flammable or explosive materials around the product. It is forbidden to use in dusty places to avoid accidents.
13. Do not place the product under the air conditioner.
14. Do not insert fingers or objects into the air outlet or inlet to prevent physical damage or malfunction of the product.

15. This product is strictly prohibited to be used in a flammable and explosive environment. The environment for using this product should not be over 30°C, and there should be at least 1 meter away from combustibles to prevent fire.
16. The fire protection cover of this heater is used to prevent direct contact with heating elements. When the heater is working, the fire protection cover must be installed in place.
17. When using the product, do not touch the metal cover of the air outlet or put your hands close to the air outlet to avoid burns.
18. Before cleaning the product or performing other maintenance, be sure to unplug the product.
19. If you need to move the product, please disconnect the power supply of the product first, and do not move the product by pulling the power cord.

Service Agreement of Smart Mobile Application Platform

Please reference Mobile Apps content: Before accepting the Agreement, you are supposed to thoroughly read all the contents of the Agreement, and fully understand its terms, especially restrictive clauses or exceptions and Privacy Notice. Restrictive clauses or exceptions are bold or highlighted in other forms to catch your attention. In case of any doubt about the terms of the Agreement, please contact the relevant business department of Tuya. You are not allowed to use the service before you have read and accepted all the terms of the Agreement, relevant agreements, and rules, etc. Once you select “agree and submit the Agreement” (see registration page for detailed wordings) and complete the registration procedure, or you use the service in any form, it will be deemed that you have read and agreed with the restriction of the Agreement and rules above. In case of any breach of the Agreement, Tuya has the right to unilaterally restrict, suspend or terminate the service for you, and has the right to investigate your relevant responsibilities.

Disposal of Electronic Products

1. Do not place the product as household waste;
2. Please dispose of discarded electronic products properly according to local regulations;
3. MOMAX encourages you to participate in the electronic recycling program.

Warranty Conditions

1. For any defect, in the judgment of our technician, caused under normal use, we are responsible for repairing free of charge 12 months commencing from the date of purchase at the discretion of our company;
2. A valid warranty card and original purchase invoice must be presented upon request of warranty service;
3. This warranty card shall not apply to the product if:
 - (a) It is consumable part(s), such as Filter, or;
 - (b) it has explicitly modified or repaired in any way by persons other than technicians of this company, or;
 - (c) it has been damaged through misuse, malicious acts, negligence, the inflow of any liquid, or;
 - (d) losses or damages are caused by force majeure or natural disasters.
4. No alteration to this warranty card will be allowed;
5. The warranty terms and conditions are subject to change without prior notice;
6. Please retain your proof of purchase for warranty service;
7. Please consult the dealer about the product compatibility with your cell phone/ PDA before purchase. Product specifications are subject to change without prior notice;
8. Please visit www.momax.net for the latest product information.

簡介

IoT 智能暖風機 (IW5S)

本產品是一款智能暖風機，整體設計比較小型，適合在家居或辦公室等場所使用。

搜尋 “IW5S” in helpdesk.momaxsmart.com

獲取有關設定和支援。

觀看最新的視頻教學，學習設置和操作您的 IW5S。

隨時了解最新資訊。



快速入門指南

1. 下載 “MOMAX Smart” 應用程式

在iOS或Android或任何平台上下載 “MOMAX Smart” 應用程式。
然後，在你的手機啟用藍牙功能。

2. 註冊

註冊一個帳戶，然後使用您的手機號碼或電子郵件地址登錄。

3. 開啟Wi-Fi

按 “+”（添加設備），選取 “MOMAX 智能暖風機” 以添加設備。


請打開機身背部的電源開關，按一下開關鍵開機，然後按住定時鍵直到Wifi指示燈快閃。按 “確定指示燈快速閃爍”，再按 “下一步” 以進行藍牙搜尋。

- 不能透過手機的藍牙清單直接配對本產品。
- 搜索過程可能需要兩分鐘。請在此期間不要執行任何操作。

4. 成功連接

如果配對成功，你會在應用程式中看到本產品的圖標。你可以修改此IW5S的名稱。確保設備已連接，結果將發送到手機的應用程式。

產品總覽



觸碰鍵	功能
 開關鍵	<ul style="list-style-type: none"> 在待機狀態下，按一次開關鍵進入自然風模式 (無指示燈)，再按一次進入暖風模式 (暖風指示燈亮)，再按一次進入熱風模式 (熱風指示燈亮)，之後再按則會重新進入自然風模式循環。 在開機狀態下，長按開關鍵關機進入待機狀態。
 定時鍵	<ul style="list-style-type: none"> 在開機狀態下，按下定時鍵可以設置定時時間分別為1H, 2H, 4H, 8H。 定時剩餘時間會通過控制面板上的指示燈顯示。如按下8H，當產品運行了4H，指示燈會自動跳到4H處，繼續運行2H，就會自動跳到2H，如此類推。 長按定時鍵約5秒，進入配網模式。
 擺動鍵	<ul style="list-style-type: none"> 在開機狀態下，按此鍵左右擺動80度。再按一次停止擺動模式。
 安全鎖	<ul style="list-style-type: none"> 在開機狀態下，長按此鍵3秒進入安全鎖狀態，此時其他鍵會不起作用。再長按3秒取消安全鎖狀態。

保護功能

傾倒保護

- 當機器發生傾倒時斷電保護，關閉PTC。設備會連續發出聲響1分鐘，直到復位後進入待機狀態。

過溫保護

- 在開啟暖風或熱風模式後長按開關鍵關機時，會先關閉PTC發熱組件，風機會延時一分鐘後關閉，以便PTC發熱組件散熱。如在開機時只開啟自然風後關閉，風機則不會延時關閉。

關機保護

- 當機器連續運行24小時，會自動關機進入待機狀態。

清潔保養

保養前，請確保拔除電源插頭。


清潔

- 關機並拔下電源插頭，待發熱器冷卻。
- 清潔進/出風口，使用蘸有中性清潔劑的微濕布擦拭暖風機的外殼。
- 拆下機器背部的隔塵網清洗。

注意：擦拭出風口時，不能有水滴落進入機器內部。

存放

- 清潔機器並完全晾乾後，套上防塵罩/袋，並放置在不被陽光直射且通風良好的地方。
- 如長時間不使用，應不定時進行通電運轉幾分鐘。



產品規格

型號	: IW5S
額定電壓/頻率	: 220-240V~, 50/60 Hz
功率	: 1500W
工作溫度	: -10℃ - 50℃
儲藏溫度	: -10℃ - 70℃
最大工作噪音	: ≤45dB
無線頻率(WiFi)	: 2.4GHz
藍牙版本	: 4.2
尺寸	: 180 x 180 x 400mm
重量	: 2.5±0.2Kg

包裝內容

1. Smart Heat IoT 智能暖風機
2. 使用說明書及保用證

注意事項

使用前，請仔細閱讀本用戶手冊，並妥善保存以備將來參考。

1. 為了避免過熱，禁止覆蓋暖風機。
2. 請勿遮擋出風口和出風口，與牆面或障礙物保持30cm以上的距離。
3. 定時清潔背部隔塵網，避免進風不夠使內部溫度過熱。
4. 請勿讓水或其他液體或者易燃性清潔劑進入產品，以免發生觸電或火災。
5. 請勿在產品周圍噴灑殺蟲劑或香水等任何可燃材料。
6. 在將產品連接電源之前，請先檢查產品銘牌標識的電壓與當地的供電電壓是否相符。
7. 使用前請檢查電源線以及插頭是否破損或損壞。如果電源線損壞，為了避免危險，必須由專業人士進行更換。
8. 禁止放在不穩或傾斜的地方上使用本產品，避免產品傾倒引起傷害或火災等事故；一定要在穩固、平整且水平的表面放置和使用本產品。
9. 產品禁止淋水，以免發生短路、觸電等危險。
10. 請勿在高溫、潮濕或有酸鹼等揮發性的地方使用。
11. 請勿在浴缸或游泳池的四周使用本產品。
12. 該產品周圍不得放置易燃或易爆物品；禁止在有粉塵的地方使用，以免發生事故。
13. 請勿將產品放在空調下方。
14. 請勿將手指或物體插入出風口或進風口，以防止產品出現物理損傷或故障。
15. 本產品嚴禁在有易燃易爆的環境中使用，且使用環境不宜超過30℃，離開可燃物至少1米以上，防止火災發生。

16. 本暖風機的防火保護罩是用於防止直接接觸發熱元件，當加熱器工作時，防火保護罩必須安裝到位。
17. 使用時，禁止觸碰出風口金屬網，或把手放近出風口，以免燙傷。
18. 清潔產品或執行其他維護之前，請務必拔掉產品的電源插頭。
19. 如需要移動產品，請先斷開產品的電源，請勿通過拉扯電源線來移動產品。

智能移動應用平台服務協議

請參考移動應用程式內容：在接受本協議之前請您務必仔細閱讀本協議的移動應用程式全部內容，充分理解條款內容，特別是限制及免責條款。限製或免除責任條款，私隱聲明，將以加粗或其他醒目形式提示您注意。如果您對本協議的條款有疑問的，請聯繫相關業務部門進行詢問。除非您已閱讀並接受本協議及相關協議、規則等所有條款，否則，您無權使用本服務。一旦您選“同意協議並提交”（具體措辭詳見註冊頁面）並完成註冊流程，或您以任何方式使用本服務，即視為您已閱讀並同意上述協議、規則等的約束。如您有違反本協議的任何行為時，智能生活有權根據您違反的情況隨時單方採取限制、中止或終止向您提供服務等措施，並有權追究您相關責任。

如何處理廢棄電子產品

1. 請勿將電子產品當成家庭廢棄物丟棄；
2. 請依當地的法例規定處理廢棄的電子產品；
3. MOMAX鼓勵您積極參與電子產品回收計劃。

保養條款

1. 由購買日期起12個月內，如產品有損壞或故障，經本公司技術人員證實為在正常使用之情況下發生，本公司將提供免費維修服務；
2. 維修時必須出示本保用證及購買商號之發票正本，如果用戶不能提供，本公司有權不提供維修服務。用戶可能需要支付相關維修費用；
3. 保用期內，出現以下條款產品保用證自動失效：
 - (a) 是可消耗的部件，例如過濾網；
 - (b) 非本公司人員恣意拆解或維修產品之任何部分；
 - (c) 錯誤的操作如：非法接駁電源，以及水、污穢物滲入產品內導致產品損；
 - (d) 不可抗拒意外事件或天然災害導致產品損壞；
4. 此保用證如經塗改，保用證自動失效；
5. 本公司有權增刪任何維修及保用條款而不作通知；
6. 如因錯誤使用本公司產品而導致手提電話或其他電子產品有任何損壞，本公司不會承擔任何責任；
7. 有關 MOMAX 原裝產品和您的手機或電子產品的相容性，請在購買時向經銷商確認。此產品規格隨時可能變更，恕不另行通告；
8. 請瀏覽 www.momax.net 瞭解最新產品資訊。

简介

IoT 智能暖风机 (IW5S)

本产品是一款智能暖风机，整体设计比较小型，适合在家居或办公室等场所使用。

搜寻“IW5S” in helpdesk.momaxsmart.com

获取有关设定和支援。

观看最新的视频教学，学习设置和操作您的 IW5S。

随时了解最新资讯。



快速入门指南

1. 下载“MOMAX Smart”应用程序

在iOS或Android或任何平台下载“MOMAX Smart”应用程序。
然后，在你的手机启用蓝牙功能。

2. 注册

注册一个帐户，然后使用您的手机号码或电子邮件地址登录。

3. 开启Wi-Fi

按“+”（添加设备），选取“MOMAX 智能暖风机”以添加设备。


请打开机身背部的电源开关，按一下开关键开机，然后按住定时键直到Wifi指示灯快闪。按“确定指示灯快速闪烁”，再按“下一步”以进行蓝牙搜寻。

- 不能透过手机的蓝牙清单直接配对本产品。
- 搜索过程可能需要两分钟。请在此期间不要执行任何操作。

4. 成功连接

如果配对成功，你会在应用程序中看到本产品的图标。你可以修改此IW5S的名称。确保设备已连接，结果将发送到手机的应用程式。

产品总览



触碰键	功能
 开关键	<ul style="list-style-type: none"> 在待机状态下，按一次开关键进入自然风模式（无指示灯），再按一次进入暖风模式（暖风指示灯亮），再按一次进入热风模式（热风指示灯亮），之后再按则会重新进入自然风模式循环。 在开机状态下，长按开关键关机进入待机状态。
 定时键	<ul style="list-style-type: none"> 在开机状态下，按下定时键可以设置定时时间分别为1H, 2H, 4H, 8H。 定时剩余时间会通过控制面板上的指示灯显示。如按下8H，当产品运行了4H，指示灯会自动跳到4H处，继续运行2H，就会自动跳到2H，如此类推。 长按定时键约5秒，进入配网模式。
 摆动键	<ul style="list-style-type: none"> 在开机状态下，按此键左右摆动80度。再按一次停止摆动模式。
 安全锁	<ul style="list-style-type: none"> 在开机状态下，长按此键3秒进入安全锁状态，此时其他键会不起作用。再长按3秒取消安全锁状态。

保护功能

倾倒保护

- 当机器发生倾倒时断电保护，关闭PTC。设备会连续发出声响1分钟，直到复位后进入待机状态。

过温保护

- 在开启暖风或热风模式后长按开关键关机时，会先关闭PTC发热组件，风机会延时一分钟后再关闭，以便PTC发热组件散热。如在开机时只开启自然风后关闭，风机则不会延时关闭。

关机保护

- 当机器连续运行24小时，会自动关机进入待机状态。

清洁保养

保养前，请确保拔掉电源插头。


清洁

- 关机并拔下电源插头，待发热器冷却。
- 清洁进/出风口，使用蘸有中性清洁剂的微湿布擦拭暖风机的外壳。
- 拆下机器背部的隔尘网清洗。

注意：擦拭出风口时，不能有水滴落进入机器内部。

存放

- 清洁机器并完全晾干后，套上防尘罩/袋，并放置在不被阳光直射且通风良好的地方。
- 如长时间不使用，应不定时进行通电运转几分钟。



产品规格

型号	: IW5S
额定电压/频率	: 220-240V~, 50/60 Hz
功率	: 1500W
工作温度	: -10℃ - 50℃
储藏温度	: -10℃ - 70℃
最大工作噪音	: ≤45dB
无线频率(WiFi)	: 2.4GHz
蓝牙版本	: 4.2
尺寸	: 180 x 180 x 400mm
重量	: 2.5±0.2Kg

包装内容

1. Smart Heat IoT 智能暖风机
2. 使用说明书及保用证

注意事项

使用前，请仔细阅读本用户手册，并妥善保存以备将来参考。

1. 为了避免过热，禁止覆盖暖风机。
2. 请勿遮挡出风口和出风口，与墙面或障碍物保持30cm以上的距离。
3. 定时清洁背部隔尘网，避免进风不够使内部温度过热。
4. 请勿让水或其他液体或者易燃性清洁剂进入产品，以免发生触电或火灾。
5. 请勿在产品周围喷洒杀虫剂或香水等任何可燃材料。
6. 在将产品连接电源之前，请先检查产品铭牌标签的电压与当地的供电电压是否相符。
7. 使用前请检查电源线以及插头是否破损或损坏。如果电源线损坏，为了避免危险，必须由专业人士进行更换。
8. 禁止放在在不平稳或倾斜的地方上使用本产品，避免产品倾倒引起伤害或火灾等事故；一定要在稳固、平整且水平的表面放置和使用本产品。
9. 产品禁止淋水，以免发生短路、触电等危险。
10. 请勿在高温、潮湿或有酸硷等挥发性的地方使用。
11. 请勿在浴缸或游泳池的四周使用本产品。
12. 该产品周围不得放置易燃或易爆物品；禁止在有粉尘的地方使用，以免发生事故。
13. 请勿将产品放在空调下方。
14. 请勿将手指或物体插入出风口或进风口，以防止产品出现物理损伤或故障。
15. 本产品严禁在有易燃易爆的环境中使用，且使用环境不宜超过30℃，离开可燃物至少1米以上，防止火灾发生。

16. 本暖风机的防火保护罩是用于防止直接接触发热元件，当加热器工作时，防火保护罩必须安装到位。
17. 使用时，禁止触碰出风口金属网，或把手放近出风口，以免烫伤。
18. 清洁产品或执行其他维护之前，请务必拔掉产品的电源插头。
19. 如需要移动产品，请先断开产品的电源，请勿通过拉扯电源线来移动产品。

智能移动应用平台服务协议

请参考移动应用程序内容：在接受本协议之前请您务必仔细阅读本协议的移动应用程序全部内容，充分理解条款内容，特别是限制及免责条款。限制或免除责任条款，私隐声明，将以加粗或其他醒目形式提示您注意。如果您对本协议的条款有疑问的，请联系相关业务部门进行询问。除非您已阅读并接受本协议及相关协议、规则等所有条款，否则，您无权使用本服务。一旦您选“同意协议并提交”（具体措施详见注册页面）并完成注册流程，或您以任何方式使用本服务，即视为您已阅读并同意上述协议、规则等的约束。如您有违反本协议的任何行为时，智能生活有权根据您违反的情况随时单方采取限制、中止或终止向您提供服务等措施，并有权追究您相关责任。

如何处理废弃电子产品

1. 请勿将电子产品当成家庭废弃物丢弃；
2. 请依当地的法规规定处理废弃的电子产品；
3. MOMAX鼓励您积极参与电子产品回收计划。

保养条款

1. 由购买日期起12个月内，如产品有损坏或故障，经本公司技术人员证实为在正常使用之情况下发生，本公司将提供免费维修服务；
2. 维修时必须出示本保用证及购买商号之发票正本，如果用户不能提供，本公司有权不提供维修服务。用户可能需要支付相关维修费用；
3. 保用期内，出现以下条款产品保用证自动失效：
 - (a) 是可消耗的部件，例如过滤网；
 - (b) 非本公司人员恣意拆解或维修产品之任何部分；
 - (c) 错误的操作如：非法接驳电源，以及水、污秽物渗入产品内导致产品损；
 - (d) 不可抗拒意外事件或自然灾害导致产品损坏；
4. 此保用证如经涂改，保用证自动失效；
5. 本公司有权增删任何维修及保用条款而不作通知；
6. 如因错误使用本公司产品而导致手提电话或其他电子产品有任何损坏，本公司不会承担任何责任；
7. 有关 MOMAX 原装产品和您的手机或电子产品的相容性，请在购买时向经销商确认。此产品规格随时可能变更，恕不另行通告；
8. 请浏览 www.momax.net 了解最新产品资讯。

momax

Warranty / 保用證 / 保用证

Model / 型號 / 型号: _____

Date of Purchase / 購買日期 / 购买日期: _____

Remarks / 備註 / 备注: _____

Customer Service / 客戶服務中心 / 客户服务中心

Hong Kong and Macau:

Unit A, 4/F., Cheung Lung Industrial Building,
10 Cheung Yee Street, Lai Chi Kok, Kowloon, Hong Kong
Hotline: 852-2402 3186 E-Mail: info@momax.net

香港及澳門:

香港九龍荔枝角長義街10號昌隆大廈4樓A室
服務熱線: 852-2402 3186 電郵: info@momax.net

中国内地:

摩米士科技(深圳)有限公司
广东省深圳市深南大道7006号万科富春东方大厦7楼
邮编: 518000 全国服务热线: 86-400-886-0010
电邮: info@momax.net.cn

Copyright © 2021 MOMAX Technology Ltd. All rights reserved.
MOMAX is registered trademark of MOMAX Technology Ltd.
All other trademarks are the property of their respective owners.

版權所有 © 2021 MOMAX Technology Ltd。保留所有權利。
MOMAX是MOMAX Technology Ltd 的註冊商標。
所有其他商標均為其各自擁有者的財產。

版权所有 © 2021 MOMAX Technology Ltd。保留所有权利。
MOMAX是MOMAX Technology Ltd 的注册商標。
所有其他商標均為其各自擁有者的財產。



www.momax.net