


INSTRUCTION MANUAL

使用說明 / 使用说明


momax

SNAPLUX

Portable LED Lamp
可携式床头燈
便携式床头灯



QL12



INTRODUCTION

介紹 / 介绍


The Portable LED Lamp is a versatile and portable lighting solution that can be used in a variety of settings. It has a sleek and modern design, the night-light is powered by a rechargeable Li-ion battery, which can be charged in 3 hours and provides up to 3 hours of maximum illumination or up to 30 hours of minimum illumination. It has three light levels, magnetic mounting design, and adjustable illumination focus.

可携式床头灯是一種多功能便攜式照明解決方案，可用於各種環境。它具有時尚而現代的設計，夜燈由可充電鋰離子電池供電，可在 3 小時內充滿電，並在最大光亮度下提供長達 3 小時的照明時間或最小光亮度下提供長達 30 小時的照明時間。它具有三個亮度級別、磁性安裝設計和可調節照明焦點。

便携式床头灯是一种多功能便携式照明解决方案，可用于各种环境。它具有时尚而现代的设计，夜灯由可充电锂离子电池供电，可在 3 小时内充满电，并在最大光亮度下提供长达 3 小时的照明时间或最小光亮度下提供长达 30 小时的照明时间。它具有三个亮度级别、磁性安装设计和可调节照明焦点。


USER GUIDE

用戶指南 / 用户指南




Before use, please use the wrench to install the screw into the metal ball.

使用前，請用扳手將螺絲安裝到金屬底座上。
使用前，請用扳手將螺絲安裝到金屬底座上。



Install the "Portable LED Lamp" to the magnetic metal ball.

將“可携式床头燈”安裝到磁性金屬球上。
將“便携式床头灯”安裝到磁性金屬球上。



User could adjust the angle through the magnetic metal ball joint design, and they could also adjust the illumination focus of light by rotating the front head.

- Clockwise is concentrated focus.
- Anti-Clockwise is diffused focus.

用戶可以通過磁性金屬球形接頭設計來調節角度，還可以通過旋轉燈前位置來調節光線的照射焦點。
- 順時針方向調節為聚焦。
- 逆時針方向調節為散焦。

用户可以通过磁性金属球形接头设计来调节角度，还可以通过旋转灯前位置来调节光线的照射焦点。
- 顺时针方向调节为聚焦。
- 逆时针方向调节为散焦。

- Long Press button to turn On/Off the LED light. The brightness will be recorded as the same setting as last time when you are turning off the power.
- Short Press button to set the Light intensity level, the sequence is following as the cycle: "Low > Medium > High > Medium > Low"
- For the Status indicator light, it will be Red color while charging and turn to Green color while fully charged.

- 長按按鈕 可開啟/關閉 LED 燈電源。關閉電源時，亮度將被記錄為關閉時的相同設置。
- 短按按鈕 設置光強度級別，順序如下循環：“低>中>高>中>低”。
- 狀態指示燈，充電時為紅色，充滿電後變為綠色。

- 長按按鈕 可开启/关闭 LED 灯电源。关闭电源时，亮度将被记录为关闭时的相同设置。
- 短按按钮 设置光强度级别，顺序如下循环：“低>中>高>中>低”。
- 状态指示灯，充电时为红色，充满电后变为绿色。

MAINTENANCE

維護 / 维护

- To keep the product surface clean and bright, please clean it regularly (recommended once every two months).
- When cleaning ordinary dust, just wipe it with a soft cleaning cloth dipped in water.
- For stains that cannot be removed with water, please wipe them with a cleaning cloth dipped in soapy water.
- Do not use highly volatile or corrosive liquids (such as gasoline, Tian Na water, etc.) to wipe the lamp to avoid discoloration or damage.

- 為保持產品表面清潔光亮，請定期清潔（建議每兩個月一次）。
- 清潔普通灰塵時，只需使用柔軟的清潔布蘸水擦拭即可。
- 對於無法用水去除的污漬，請用清潔布蘸肥皂水擦拭。
- 請勿使用高揮發性或腐蝕性液體（如汽油、天納水等）擦拭燈具，以免變色或損壞。

- 为保持产品表面清洁光亮，请定期清洁（建议每两个月一次）。
- 清洁普通灰尘时，只需使用柔软的清抹布蘸水擦拭即可。
- 对于无法用水去除的污渍，请用清洁布蘸肥皂水擦拭。
- 请勿使用高挥发性或腐蚀性液体（如汽油、天纳水等）擦拭灯具，以免变色或损坏。



www.momax.net

SPECIFICATION

產品規格 / 产品规格

| | |
|-------------------|---|
| MODEL: QL12 | |
| USB-C Input | : 5V = 1A |
| Power | : 4W |
| Battery capacity | : 1200mAh |
| Charging time | : 3 hours |
| Working time | : Up to 3 hours (Brightest) or 30 hours (Darkest) |
| Type | : LED |
| Luminous | : 130lm (max.) |
| Luminous range | : 120° |
| Color Temperature | : 4000K |
| CRI(ra) | : >=80 |
| Material | : ABS+PMMA |
| Size | : Φ33 x 127 mm |
| Weight | : 108g ± 10g |

| | |
|----------|--------------------------|
| 型號: QL12 | |
| USB-C輸入 | : 5V = 1A |
| 功率 | : 4W |
| 電池容量 | : 1200mAh |
| 充電時間 | : 3 小時 |
| 續航時間 | : 長達>3小時(最亮)或者 >30小時(最暗) |
| 類型 | : LED |
| 光通量 | : 130lm (max.) |
| 發光範圍 | : 120° |
| 色溫 | : 4000K |
| 顯色指數 | : >=80 |
| 材質 | : ABS+PMMA |
| 尺寸 | : Φ33 x 127 mm |
| 重量 | : 108g ± 10g |

| | |
|----------|--------------------------|
| 型号: QL12 | |
| USB-C输入 | : 5V = 1A |
| 功率 | : 4W |
| 电池容量 | : 1200mAh |
| 充电时间 | : 3 小时 |
| 续航时间 | : 长达>3小时(最亮)或者 >30小时(最暗) |
| 类型 | : LED |
| 光通量 | : 130lm (max.) |
| 发光范围 | : 120° |
| 色温 | : 4000K |
| 显色指数 | : >=80 |
| 材质 | : ABS+PMMA |
| 尺寸 | : Φ33 x 127 mm |
| 重量 | : 108g ± 10g |

WARNING

- Do not dismantle or modify the product;
- Do not use this product on surfaces of high-temperature flammable objects or in damp environments to avoid product damage, short circuits that can cause fires, or electric shock accidents;
- Do not keep or use the product near heat sources;
- Do not let water or any other liquid flows into the inside part of the product's interface. This would cause damages to the product;
- This product is for indoor use only;
- Avoid high processor load in long running loops or while charging;
- The light source of this LED lamp is not replaceable. When the light source reaches the end of its life, the entire lamp should be replaced;
- This product is including a built-in battery. Do not throw it into the fire to avoid explosion. When the LED lamp is working, do not look directly at the light source to avoid damaging your eyesight
- In case of overheating, stop using the product.
- Please keep the magnetic area of the device free of dirt, oil and water stains to avoid affecting the magnetic force between the magnetic metal ball and the magnet.

DISPOSAL OF ELECTRONIC PRODUCTS

- Do not place the product as household waste;
- Please dispose of discarded electronic products properly according to local regulations.
- MOMAX encourages you to participate in electronics recycling program.

WARRANTY CONDITIONS

- For any defect, in the judgment of our technician, caused under normal use, we are responsible for repairing free of charges 12 months commencing from the date of purchase at the discretion of our company;
- A valid warranty card and original purchase invoice must be presented upon request of warranty service;
- This warranty card shall not apply to the product if:
(a) it has explicitly modified or repaired in any way by persons other than technicians of this company, or;
(b) it has been damaged through misuse, malicious acts, negligence, inflow of any liquid, or;
(c) losses or damages are caused by force majeure or natural disasters.
- No alteration to this warranty card will be allowed;
- The warranty terms and conditions are subject to change without prior notice;
- Please retain your proof of purchase for warranty service;
- Please consult the dealer about the product compatibility with your cell phone/ PDA before purchase. Product specifications are subject to change without prior notice;
- Please visit www.momax.net for latest product information.

警告

- 請勿自行拆開或改裝本產品；
- 請勿在高溫易燃物體表面或潮濕的環境使用本產品，以避免產品損壞、短路導致火災或觸電事故；
- 請勿將產品靠近熱源或熱源附近充電；

- 請勿將水或其它液體流入本產品介面內部，導致本產品損壞；
- 本產品僅供室內使用；
- 使用或充電期間避免長時間運行高耗能的程式；
- 此產品的光源不可更換。當光源達到其使用壽命時，應更換整個產品；
- 本產品包含內置電池。請勿將其投入火中，以免爆炸。LED燈工作時，請勿直視光源，以免損傷視力；
- 如出現過熱，請停止使用。
- 請保持設備磁性區域無污垢、油污、水漬，以免影響磁性金屬球與磁鐵之間的磁力。

如何處理廢棄電子產品

- 請勿將電子產品當成家庭廢棄物丟棄；
- 請依當地的法例規定處理廢棄的電子產品；
- MOMAX鼓勵您積極參與電子產品回收計劃。

保養條款

- 由購買日期起12個月內，如產品有損壞或故障，經本公司技術人員證實為在正常使用之情況下發生，本公司將提供免費維修服務；
- 維修時必須出示本保用證及購買商號之發票正本，如果用戶不能提供，本公司有權不提供維修服務。用戶可能需要支付相關維修費用；
- 保用期內，出現以下條款產品保用證自動失效：
(a) 非本公司人員恣意拆解或維修產品之任何部分；
(b) 錯誤的操作如：非法接駁電源，以及水、污穢物滲入產品內導致產品損壞；
(c) 不可抗拒意外事件或天然災害導致產品損壞；
- 此保用證如經塗改，保用證自動失效；
- 本公司有權增刪任何維修及保用條款而不作通知；
- 如因錯誤使用本公司產品而導致手提電話或其他電

- 子產品有任何損壞，本公司不會承擔任何責任；
- 有關 MOMAX 原裝產品和您的手機或電子產品的相容性，請在購買時向經銷商確認。此產品規格隨時可能變更，恕不另行通知；
- 請瀏覽 www.momax.net 瞭解最新產品資訊。

警告

- 請勿自行拆開或改裝本產品；
- 請勿在高溫易燃物體表面或潮濕的環境使用本產品，以避免產品損壞、短路導致火災或觸電事故；
- 請勿將產品靠近熱源或熱源附近充電；
- 請勿將水或其它液體流入本產品介面內部，導致本產品損壞；
- 本產品僅供室內使用；
- 使用或充電期間避免長時間運行高耗能的程式；
- 此產品的光源不可更換。當光源達到其使用壽命時，應更換整個產品。
- 本產品包含內置電池。請勿將其投入火中，以免爆炸。LED燈工作時，請勿直視光源，以免損傷視力；
- 如出現過熱，請停止使用。
- 請保持設備磁性區域無污垢、油污、水漬，以免影響磁性金屬球與磁鐵之間的磁力。

如何處理废弃电子产品

- 請勿將电子产品当成家庭废弃物丢弃；
- 請依當地的法例規定處理废弃的电子产品；
- MOMAX鼓勵您積極參與电子产品回收計劃。

保养条款

- 由购买日期起12个月内，如产品有损坏或故障，经本公司技术人员证实为在正常使用之情况下发生，本公司将提供免费维修服务；
- 维修时必须出示本保用证及购买商号之发票正本，如

- 果用户不能提供，本公司有权不提供维修服务。用户可能需要支付相关维修费用；
- 保用期內，出現以下條款產品保用證自動失效：
(a) 非本公司人員恣意拆解或維修產品之任何部分；
(b) 錯誤的操作如：非法接駁電源，以及水、污穢物滲入產品內導致產品損壞；
(c) 不可抗拒意外事件或天然災害導致產品損壞；
- 此保用證如經塗改，保用證自動失效；
- 本公司有權增刪任何維修及保用條款而不作通知；
- 如因錯誤使用本公司產品而導致手提電話或其他電子產品有任何損壞，本公司不會承擔任何責任；
- 有關 MOMAX 原裝產品和您的手機或電子產品的相容性，請在購買時向經銷商確認。此產品規格隨時可能變更，恕不另行通知；
- 請瀏覽 www.momax.net 了解最新產品資訊。

有毒有害物質或元素附表

| 部件名稱 | 有毒有害物質或元素 | | | | | |
|------|-----------|--------|--------|-------------------------|-------------|---------------|
| | 鉛 (Pb) | 汞 (Hg) | 鎘 (Cd) | 六价鉻 (Cr ^{VI}) | 多環芳烴 (PAHs) | 多溴二噁英 (PBDEs) |
| 主殼 | X | O | O | O | O | O |
| 附件 | X | O | O | O | O | O |

O: 表示該有害物質在該部件中的所有材料中的含量均在 GB/T 26572 標準規定的限量要求以下
X: 表示該有害物質含量至少在該部件的某一材料材料中的含量超過 GB/T 26572 標準規定的限量要求
注: 本產品標有“X”的區域是: 現階段沒有可供選擇的替代材料或部件



momax

WARRANTY/保用證/保用证

Model/型號/型号:
Date of Purchase/購買日期/购买日期:
Remarks/備註/备注:

Customer Service/客戶服務中心/客户服务中心

Hong Kong and Macau:
Unit A, 4/F., Cheung Lung Ind. Bldg., 10 Cheung Yee Street,
Lai Chi Kok, Kowloon, Hong Kong
Hotline: 852-2402 3186 E-Mail: info@momax.net
香港及澳門:
香港九龍荔枝角長義街10號昌隆大廈4樓A室
服務熱線: 852-2402 3186 電郵: info@momax.net

中國內地:
摩米士科技(深圳)有限公司
廣東省深圳市深南大道7006號万科富春東方大廈7樓
郵編: 518000 全國服務熱線: 86-400-886-0010
電郵: info@momax.net.cn

Copyright© 2023 MOMAX Technology Ltd. All rights reserved.
MOMAX is registered trademark of MOMAX Technology Ltd.
All other trademarks are the property of their respective owners.
版權所有 ©2023 MOMAX Technology Ltd. 保留所有權利。
MOMAX是 MOMAX Technology Ltd 的註冊商標。
所有其他商標均為其各自擁有者的財產。
版權所有 ©2023 MOMAX Technology Ltd. 保留所有權利。
MOMAX是 MOMAX Technology Ltd 的註冊商標。所有其他商標均為其各自擁有者的財產。